

**NOTES:**


1. FOR SUPPLY CONNECTIONS USE No. 14 AWG OR LARGER WIRES RATED FOR AT LEAST 75°C (167°F) "USE COPPER CONDUCTORS ONLY".
2. IF READING APPEARS TO BE OUT OF RANGE, REVERSE POTENTIAL LEADS TO SUIT
3. DIRECT CONNECT TRANSUCERS ARE AVAILABLE TO 600 V(ac)
4. PHASES CAN BE ROTATED ON THREE PHASE UNITS.
5. IT IS GOOD PRACTICE TO CONNECT ONE SIDE OF THE PT TO EARTH GROUND

**ATTENTION:**

IF THE TRANSUCER IS MOUNTED ON A NON-METALLIC OR UNGROUNDED SURFACE THE INSTALLER MUST PROVIDE THE MEANS FOR GROUNDING AND BONDING AS PER NEC (NATIONAL ELECTRIC CODE) REQUIREMENTS

**CONNECTION DIAGRAM**

REVISION
----------

 <b>MTECH</b> <small>MEASUREMENT TECHNOLOGIES, LTD          Voice 817-442-9930          Web Site: www.mtech.biz</small>	DRAWN TONY C.	TITLE <b>PHASE ANGLE TRANSUCER CONNECTION DIAGRAM</b>		
	CHECKED T.N			
	APPROVED T.N	DRAWING No. PA-1	SHEET 1 of 1	REV. 0
	DATE MAY, 1994			